


Step 4: Install the ceiling. Make sure that the

(Top of Housing hidden for clarity)


Step 5: Cut ceiling hole that matches the position and

(Top of Housing hidden for clarity)

Step 6: Install product (refer to Product



inter•lux	Phone: (410)381-1497	Web: www.inter-lux.com	PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF Inter-Iux. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF Inter-Iux IS PROHIBITED.		OF 3
*Inter-lux reserves the ri	ght to make changes to this product and related installation	instructions at any time without prior notice.	DRAWING NOT TO SCALE	940-B100RRG	REV N/C




MOA Step 1: Complete up to and includng step 5 of the Chicago Plenum Surface Mount Installation Steps. (Refer to Ceiling Thickness Key before installing)

Step 4: Bring Mounting Clips (C) up through the Housing (A)(1) and push them into their respective slots as shown (2). Make sure

e safety cable to the Light Engine (D)(1)

(Ceiling hidden for clarity)


Step 5: Attach the safety cable to the Light Engine (D)(1). Then make the connection between the DC Power wires Step 3: Pull DC Power wires through Housing (A). Push the two larger Mounting Clips (B) into shown slots until you hear the first tab engage. Then position the Housing (A) into the ceiling hole and push it all the way in.



Step 6: Push the Light Engine (D) up into the Housing (A) until it locks into the spring latch as shown.


MOUNTING INSTALLATION STEPS


Step 2: Locate the DC Power wires. Then pull them through the hole in the Plenum Box and ceiling.



that the	Mounting (the Hous	Clips (B) ar sing (A) is s			nough so and Light Engine (D)(2) using the supplied connectors.				
				C		2			
(CP/IC Housing hic					den for clarity)		(CP/IC Housing hidde	en for clarity)	 (CP/IC Housing hidden for clarity)
	Ceiling Thickness Key								
Material	Wood	Gypsum	Metal	Tile					
Minimum	1/4"	1/2"	1/16"	1/2"					
Maximum	1"	1"	11/16"	1"					

inter•lux	Phone: (410)381-1497	Web: www.inter-lux.com	PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF Inter-Iux. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF Inter-Iux IS PROHIBITED.	SHEET 2	OF 3
*Inter-lux reserves the	right to make changes to this product and related installation	instructions at any time without prior notice.	DRAWING NOT TO SCALE	940-B100RRG	REV N/C





0-10V Dimming **DES 1% Dimming** Line (Black) To Line Voltage Switched Hot (Black) To Line Voltage +VDC (Red or Brown) +VDC (Red or Brown) Neutral (White) Neutral (White) ¢ Ground (Green) ¢ Ground (Green) LED light LED light Power Supply **Power Supply** engine engine To 0-10V Dim To Ecosystem Digital Link Dimming + (Purple) Control E1 (Purple) -VDC (Black or Blue) -VDC (Black or Blue) Dimming - (Grey) E2 (Purple) Ť NOTE: SHOWN DRIVERS ARE INTER-LUX PROVIDED. FOR NON INTER-LUX PROVIDED DRIVERS PLEASE REFER TO DRIVER MANUFACTURER. THE USE OF NON INTER-LUX PROVIDED DRIVERS VOIDS PRODUCT WARRANTY. PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF Inter-lux. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITEN PERMISSION OF Inter-lux. IS PROHIBITED. Phone: (410)381-1497 Web: www.inter-lux.com SHEET 3 OF 3 interolux

*Inter-lux reserves the right to make changes to this product and related installation instructions at any time without prior notice.

DRAWING NOT TO SCALE 940-B100RRG REV N/C