

**WARNING:**  
INSTALL PRODUCT IN ACCORDANCE WITH LOCAL AND NATIONAL ELECTRICAL CODES; BY A QUALIFIED ELECTRICIAN.


**WARNING:**  
FAILURE TO COMPLY WITH THE INSTALLATION INSTRUCTIONS MAY RESULT IN DEATH OR SERIOUS INJURY.

**WARNING:**  
READ ALL SAFETY INSTRUCTIONS INCLUDED WITH LUMINAIRE BEFORE INSTALLING LUMINAIRE.


**CAUTION:**  
THIS IS AN ELECTRONIC DEVICE. CARE MUST BE TAKEN DURING STORAGE AND HANDLING. STORE IN A CLEAN, COOL AND DRY LOCATION. ELECTROSTATIC DISCHARGE (ESD) CAN HARM THIS PRODUCT. AVOID STATIC DISCHARGE WHILE HANDLING THIS PRODUCT.

**CAUTION:**  
INTER-LUX IS NOT RESPONSIBLE FOR THE STRUCTURAL INTEGRITY OF THE BUILDING TO SUPPORT THE LUMINAIRE. ADDITIONAL BACKING MAY BE REQUIRED.


ISOMETRIC VIEWS




PACKAGE INCLUDES:




ITEMS NEEDED (SUPPLIED BY OTHERS):




MOUNTING DIMENSIONS



MOUNTING POSITIONS



PRODUCT



SURFACE MOUNT INSTALLATION STEPS

Step 1: Attach the Hangars (A) to the CP/IC Housing (B).

Step 2: Determine mounting position, adjust width of Hangars (A) until flush with surface.

2A- Anchor clips into wood joists with hammer and lock hangers.  
OR  
2B- Secure angle bars with screws to ceiling grid and lock hangers.


Step 3: Install your Remote Driver (C) and pull DC Power through the knockout into the Housing (B).


Step 4: Install the ceiling. Make sure that the Housing (B) is flat on top of the ceiling.


Step 5: Cut ceiling hole that matches the position and dimensions of the Construction Plate (B) hole.

Step 6: Install product (refer to Product Installation Instructions on back).



**WARNING:**  
INSTALL PRODUCT IN ACCORDANCE WITH LOCAL AND NATIONAL ELECTRICAL CODES; BY A QUALIFIED ELECTRICIAN.


**WARNING:**  
FAILURE TO COMPLY WITH THE INSTALLATION INSTRUCTIONS MAY RESULT IN DEATH OR SERIOUS INJURY.

**WARNING:**  
READ ALL SAFETY INSTRUCTIONS INCLUDED WITH LUMINAIRE BEFORE INSTALLING LUMINAIRE.


**CAUTION:**  
THIS IS AN ELECTRONIC DEVICE. CARE MUST BE TAKEN DURING STORAGE AND HANDLING. STORE IN A CLEAN, COOL AND DRY LOCATION. ELECTROSTATIC DISCHARGE (ESD) CAN HARM THIS PRODUCT. AVOID STATIC DISCHARGE WHILE HANDLING THIS PRODUCT.

**CAUTION:**  
INTER-LUX IS NOT RESPONSIBLE FOR THE STRUCTURAL INTEGRITY OF THE BUILDING TO SUPPORT THE LUMINAIRE. ADDITIONAL BACKING MAY BE REQUIRED.


ISOMETRIC VIEWS




PACKAGE INCLUDES:




ITEMS NEEDED (SUPPLIED BY OTHERS):




MOUNTING DIMENSIONS




MOUNTING OPTIONS




DIFFUSER POSITIONS




**TURN OFF MAIN POWER BEFORE PROCEEDING!**  
Step 1: Complete up to and including step 4 of the Chicago Plenum Surface Mount Installation Steps. (Refer to Ceiling Thickness Key before installing)

Step 2: Locate the DC Power wires. Then pull them through the hole in the Plenum Box and ceiling.




(Ceiling hidden for clarity)

Step 3: Pull DC Power wires through Housing (B).




(Ceiling hidden for clarity)

Step 4: Position Housing (A) into ceiling/Plenum hole. Then squeeze the Mounting Clips (A) together and push the housing up into the ceiling.





(CP/IC Housing hidden for clarity)

Step 5: Make the connection between the Low Voltage leads and the Light Engine (B) using supplied wire connectors.



(CP/IC Housing hidden for clarity)

Step 6: Insert the Light Engine (B) into the Housing (A). Make sure the clips on the sides of the Light Engine (B) catch on the sides of the Housing (A). See Section View.




(CP/IC Housing hidden for clarity)


Ceiling Thickness Key				
Material	Wood	Gypsum	Metal	Tile
Minimum	1/4"	1/2"	1/16"	1/2"
Maximum	1 - 3/4"	1 - 3/4"	11/16"	1 - 3/4"



Wiring Key



Driver Wiring Diagrams



NOTE: SHOWN DRIVERS ARE INTER-LUX PROVIDED. FOR NON INTER-LUX PROVIDED DRIVERS PLEASE REFER TO DRIVER MANUFACTURER. THE USE OF NON INTER-LUX PROVIDED DRIVERS VOIDS PRODUCT WARRANTY.