

### Chicago Plenum/Insulated Ceiling Housing INSTALLATION INSTRUCTIONS

FINISH: GALVANIZED STEEL

PART. NO. CP/IC-WG-P100SAG-X



INSTALL PRODUCT IN ACCORDANCE WITH LOCAL AND NATIONAL ELECTRICAL CODES; BY A QUALIFIED ELECTRICIAN.



FAILURE TO COMPLY WITH THE INSTALLATION INSTRUCTIONS MAY RESULT IN DEATH OR SERIOUS INJURY.

WARNING:

READ ALL SAFETY INSTRUCTIONS INCLUDED WITH LUMINAIRE BEFORE INSTALLING LUMINAIRE


#### CAUTION:

THIS IS AN ELECTRONIC DEVICE. CARE MUST BE TAKEN DURING STORAGE AND HANDLING. STORE IN A CLEAN, COOL AND DRY LOCATION. ELECTROSTATIC DISCHARGE (ESD) CAN HARM THIS PRODUCT. AVOID STATIC DISCHARGE WHILE HANDLING THIS PRODUCT.


#### CAUTION:

INTER-LUX IS NOT RESPONSIBLE FOR THE STRUCTURAL INTEGRITY OF THE BUILDING TO SUPPORT THE LUMINAIRE. ADDITIONAL BACKING MAY BE REQUIRED.


### ISOMETRIC VIEWS




#### **PACKAGE INCLUDES:**




#### ITEMS NEEDED (SUPPLIED BY OTHERS):




#### MOUNTING DIMENSIONS




#### **MOUNTING POSITIONS**



#### **PRODUCT**




### SURFACE MOUNT INSTALLATION STEPS




(Top of Housing hidden for clarity)


Step 2: Determine mounting position, adjust width of Hangers (A) until flush with surface. 2A- Anchor clips into wood joists




(Top of Housing hidden for clarity)








Step 5: Cut ceiling hole that matches the position and dimensions of the Construction Plate (B) hole.



Step 6: Install product (refer to Product



DIMENSIONS ARE IN INCHES TOLERANCES: FRACTIONAL ANGULAR: MACH ± 0.5 BEND ± 1.0 ONE PLACE DECIMAL  $\pm\,\,$  0.05 TWO PLACE DECIMAL ± 0.01

THREE PLACE DECIMAL ± 0.005

3RD ANGLE PROJECTION



PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF Inter-lux. ANY REPRODUCTION
IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF Inter-lux IS PROHIBITED.

SHEET 1 OF 3 DRAWING NOT TO SCALE 940-P100SAG REV N/C



## Whitegoods Plaster 100 Square Angled Gimbal 22

INSTALLATION INSTRUCTIONS

FINISH: WHITE

PART. NO. CP/IC-WG-P100SAG-X



INSTALL PRODUCT IN ACCORDANCE WITH LOCAL AND NATIONAL ELECTRICAL CODES; BY A QUALIFIED ELECTRICIAN.



FAILURE TO COMPLY WITH THE INSTALLATION INSTRUCTIONS MAY RESULT IN DEATH OR SERIOUS INJURY.



WARNING:

READ ALL SAFETY INSTRUCTIONS INCLUDED WITH LUMINAIRE BEFORE INSTALLING LUMINAIRE


#### CAUTION:

THIS IS AN ELECTRONIC DEVICE. CARE MUST BE TAKEN DURING STORAGE AND HANDLING. STORE IN A CLEAN, COOL AND DRY LOCATION. ELECTROSTATIC DISCHARGE (ESD) CAN HARM THIS PRODUCT. AVOID STATIC DISCHARGE WHILE HANDLING THIS PRODUCT.


#### CAUTION:

INTER-LUX IS NOT RESPONSIBLE FOR THE STRUCTURAL INTEGRITY OF THE BUILDING TO SUPPORT THE LUMINAIRE. ADDITIONAL BACKING MAY BE REQUIRED.







#### **PACKAGE INCLUDES:**




#### ITEMS NEEDED (SUPPLIED BY OTHERS):




#### MOUNTING DIMENSIONS



### **MOUNTING OPTIONS**




#### **DIFFUSER POSITIONS**



### **TURN OFF MAIN POWER BEFORE PROCEEDING!**


Step 1: Complete up to and including step 5 of the Chicago Plenum Surface Mount Installation Steps. (Refer to Ceiling Thickness Key before installing)



the housing is secure in the ceiling.


### **MOUNTING INSTALLATION STEPS**

Step 2: Locate the DC Power wires. Then pull them through the hole in the Plenum Box and ceiling.



Dimming Leads through Housing (A).


Step 3: Pull DC Power and



down the Housing (A) into the ceiling using holes in the lattice.


Step 4a: Position the Housing (A) into

hole and push it all the way in. Screw




(CP/IC Housing hidden for clarity)

Step 4b: Before placement into the ceiling, push Mounting Clips (B) into their slots up to the first tab. Then insert Housing (A) into the ceiling. Make sure that each clip is pushed down until




Step 5: Once Housing (A) is flush with the ceiling and secured plaster over the lattice

(Ceiling hidden for clarity)




Step 8: Attach the Safety Cable to the Light Engine (C)(1). Then make the connection between the DC Power wires and the Light Engine (C) using the supplied connectors (2).



(CP/IC Housing hidden for clarity)

Step 9: Push the Light Engine (C) up into the Housing (A) until it locks into the spring latch Tilt light into desired position (max 30 degree tilt).



(CP/IC Housing hidden for clarity)

(* , * ) * * * * * * * * * * * * * * * *				
Ceiling Thickness Key				
Material	Wood	Gypsum	Metal	Tile
Minimum	1/4"	1/2"	1/16"	1/2"
Maximum	1"	1"	11/16"	1"

Web: www.inter-lux.com

SHEET 2 OF 3

Phone: (410)381-1497 \*Inter-lux reserves the right to make changes to this product and related installation instructions at any time without prior notice. PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF Inter-lux. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF Inter-lux IS PROHIBITED.

# Wiring Instructions



INSTALL PRODUCT IN ACCORDANCE WITH LOCAL AND NATIONAL ELECTRICAL CODES; BY A QUALIFIED ELECTRICIAN.



FAILURE TO COMPLY WITH THE INSTALLATION INSTRUCTIONS MAY RESULT IN DEATH OR SERIOUS INJURY

# w.


READ ALL SAFETY INSTRUCTIONS
INCLUDED WITH LUMINAIRE BEFORE
INSTALLING LUMINAIRE.

#### CAUTION

THIS IS AN ELECTRONIC DEVICE. CARE MUST BE TAKEN DURING STORAGE AND HANDLING. STORE IN A CLEAN, COOL AND DRY LOCATION. ELECTROSTATIC DISCHARGE (ESD) CAN HARM THIS PRODUCT. AVOID STATIC DISCHARGE WHILE HANDLING THIS PRODUCT.

#### CALITION

INTER-LUX IS NOT RESPONSIBLE FOR THE STRUCTURAL INTEGRITY OF THE BUILDING TO SUPPORT THE LUMINAIRE. ADDITIONAL BACKING MAY BE REQUIRED.





DRIVER MANUFACTURER. THE USE OF NON INTER-LUX PROVIDED DRIVERS VOIDS PRODUCT WARRANTY.

Web: www.inter-lux.com

NOTE: SHOWN DRIVERS ARE INTER-LUX PROVIDED. FOR NON INTER-LUX PROVIDED DRIVERS PLEASE REFER TO

Phone: (410)381-1497

SHEET 3 OF 3