

New Construction Housing Integral Driver

INSTALLATION INSTRUCTIONS



INSTALL PRODUCT IN ACCORDANCE WITH LOCAL AND NATIONAL ELECTRICAL CODES; BY A QUALIFIED ELECTRICIAN.



FAILURE TO COMPLY WITH THE INSTALLATION INSTRUCTIONS MAY RESULT IN DEATH OR SERIOUS INJURY


WARNING: READ ALL SAFETY INSTRUCTIONS INCLUDED WITH LUMINAIRE BEFORE INSTALLING LUMINAIRE

CAUTION:


THIS IS AN ELECTRONIC DEVICE. CARE MUST BE TAKEN DURING STORAGE AND HANDLING. STORE IN A CLEAN, COOL AND DRY LOCATION. ELECTROSTATIC DISCHARGE (ESD) CAN HARM THIS PRODUCT. AVOID STATIC DISCHARGE WHILE HANDLING THIS PRODUCT.

INTER-LUX IS NOT RESPONSIBLE FOR THE STRUCTURAL INTEGRITY OF THE BUILDING TO SUPPORT THE LUMINAIRE. ADDITIONAL BACKING MAY BE REQUIRED.


ISOMETRIC VIEWS




PACKAGE INCLUDES:



ITEMS NEEDED (SUPPLIED BY OTHERS):




MOUNTING DIMENSIONS



PRODUCT POSITIONS

Hangers will be able to attach to all sides of the construction plate as shown below.




CEILING HOLE CUT-OUT CHART


CEILING HOLE COT-OUT CHART		
	Round	Square
GDL	Ø 2-3/4''	N/A
GDL Mark II	Ø 2-3/4''	□2-3/4"
ProTools D	Ø 4-3/4''	□ 4-3/4"
ProTools DL	Ø 4-3/4''	□ 4-3/4"
ProTools DLX	Ø 4-3/4''	□ 4-3/4"

SURFACE MOUNT INSTALL


Step 1: Determine mounting position, adjust width of Hangers (A) until flush with surface. Then install using one of the following methods.




Step 2: Install Integral Driver(s). Then pull AC wires to New Construction Housing (B) and make connections. Install the ceiling and ensure the New Construction Housing (B) ends up flat once ceiling is installed.



Step 3: Cut ceiling hole that matches the position and dimensions of the Landing Pan hole. For openings less than \emptyset 3.9", the ceiling must be accessible.



Step 4: Once installation of New Construction Housing is complete, refer to



Phone: (410)381-1497

Web: www.inter-lux.com

PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF Inter-lux. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF Inter-lux IS PROHIBITED.

SHEET 1 OF 2



Wiring Instructions



INSTALL PRODUCT IN ACCORDANCE VITH LOCAL AND NATIONAL ELECTRICAL CODES; BY A QUALIFIED ELECTRICIAN.




FAILURE TO COMPLY WITH THE INSTALLATION INSTRUCTIONS MAY RESULT IN DEATH OR SERIOUS INJURY.

WARNING:

READ ALL SAFETY INSTRUCTIONS INCLUDED WITH LUMINAIRE BEFORE INSTALLING LUMINAIRE

THIS IS AN ELECTRONIC DEVICE. CARE MUST BE TAKEN DURING STORAGE AND HANDLING. STORE IN A CLEAN, COOL AND DRY LOCATION. ELECTROSTATIC DISCHARGE (ESD) CAN HARM THIS PRODUCT. AVOID STATIC DISCHARGE WHILE HANDLING THIS PRODUCT

INTER-LUX IS NOT RESPONSIBLE FOR THE STRUCTURAL INTEGRITY OF THE BUILDING TO SUPPORT THE LUMINAIRE. ADDITIONAL BACKING MAY BE REQUIRED.





PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF Inter-lux. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF Inter-lux IS PROHIBITED. Phone: (410)381-1497 Web: www.inter-lux.com SHEET 2 OF 2

ALL SHOWN DRIVERS ARE INTER-LUX PROVIDED. FOR NON INTER-LUX PROVIDED DRIVERS PLEASE REFER TO DRIVER MANUFACTURER. THE USE OF NON INTER-LUX PROVIDED DRIVERS VOIDS PRODUCT WARRANTY.