LED-FGI756-E

INSTALLATION INSTRUCTIONS




ENVELOPE IP66 WALL RECESSED



Baltimore, MD 21227 Phone (410) 381-1497 inter-lux.com





ELECTRICIAN

WARNING:

INSTALL PRODUCT IN ACCORDANCE

WITH LOCAL AND NATIONAL ELECTRICAL CODES BY A QUALIFIED

INJURY.

WARNING:

FAILURE TO COMPLY WITH THE INSTALLATION INSTRUCTIONS MAY RESULT IN DEATH OR SEVERE



WARNING:

READ ALL SAFETY INSTRUCTIONS INCLUDED WITH LUMINAIRE BEFORE INSTALLING LUMINAIRE. SAVE INSTRUCTIONS FOR FUTURE USE.

2

CAUTION:


THIS IS AN ELECTRONIC DEVICE. CARE MUST BE TAKEN DURING STORAGE AND HANDLING. STORE IN A CLEAN, COOL AND DRY LOCATION. ELECTROSTATIC DISCHARGE (ESD) CAN HARM THIS PRODUCT. AVOID STATIC DISCHARGE WHILE HANDLING THIS PRODUCT.


CAUTION:


INTER-LUX IS NOT RESPONSIBLE FOR THE STRUCTURAL INTEGRITY OF THE BUILDING TO SUPPORT THE LUMINAIRE. ADDITIONAL BACKING MAY BE REQUIRED.

LOCATE AND REVIEW ANY CONTRUCTION PLANS AND INTER-LUX RECORD DRAWINGS FOR ALL FIXTURE RUNS. IT IS RECOMMENDED TO LOCARE AND LAY OUT ALL COMPONENTS FOR EACH FIXTURE "RUN". A FIXTURE RUN TIPICALLY CONSISTS OF JOINERS, LENGHTS OF HOUSING, AND ENDCAPS. BE SURE TO IDENTIFY ALL CORRECT LENGHTS FOR EACH FIXTURE RUN.


INSTALLATION INSTRUCTIONS








Cut the correct size opening in the wall







WIRING DIAGRAM

SINGLE FIXTURE

MULTIPLE FIXTURE WIRED IN PARALLEL (Constant Voltage)





The number of fixtures on a single output will vary depending on the specific LED driver.

Refer to the specific wiring diagram on https://www.inter-lux.com/wiring-diagrams/

| Secondary Cable Colours | Pole |
|-------------------------|------|
| Red wire | + |
| Blue wire | - |

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED

MOUNTING INSTRUCTIONS

READ ALL OF THESE INSTRUCTIONS BEFORE INSTALLING FIXTURES

- · CAUTION: USE ONLY WITH CLASS 2 POWER UNIT
- · Keep all of the instructions for future reference
- · Turn off power before installing fixture
- · Installation is to be performed by a qualified electrician only
- All installations must conform to the National Electrical Code as well as all local jurisdictional codes and regulations
- · Any modification of the luminaire will void any and all written or implied warranties
- The manufacture accepts no responsibility for damage to persons or property airing through improper use or installation