

Aline 70

SURFACE Installation Instructions


inter•lux



NOTE:

Additional mounting hardware provided for installation where junction box is not available.

1	2"x 3" junction box and power feed (by others)
2	Mounting channel
3	Mounting screws to junction box 6-32 x 3/4" long, round head (by others)
4	Mounting hardware (provided)
5	Fixture power wires
6	Fixture housing mounting screws (x2)
7	Fixture housing



INSTRUCTIONS:

1. Unscrew fixture housing mounting screws and remove fixture housing from the mounting channel.
2. Bring the electrical power feed through the hole in mounting channel, secure mounting channel to the junction box (screws by others) and to the ceiling / wall using mounting hardware provided. If junction box is not available, secure mounting channel to the ceiling / wall using additional mounting hardware provided.
3. Splice the fixture power wires and power feed as required and secure fixture housing back into place.
Wires for connection are clearly labeled.
4. Energize.

GENERAL NOTE:

- * Turn power off before beginning.
- * Do not connect to an ungrounded supply.
- * Consult a qualified electrician to ensure correct branch circuit conductor.
- * This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- * Save these instructions.

