


Unpack luminaire unit. Unit ships in *three* major parts: Fixture Insert/Driver Box Assembly, Plaster Trim Housing, and Lens /Cover, unless Remote Driver version was supplied, Plenumrated cable with bare leads is also provided. In this configuration, integral conduit and driver box are not included. However, a strain relief is added to where the low voltage wires exit. Remote drivers and housings are supplied by Inter-lux.







whitegoods

Installation Instructions

Downlight

Round and Square Accent Wall Wash Recessed Plaster Trim


Page 2


Step 2 - Ceiling Preparation

Cut appropriate size opening in the ceiling as shown above. Clear any insulation at least 3"from any part of the fixture or driver enclosure.

Step 3 - Housing Orientation and Insertion

- Before screwing plaster trim into ceiling, orient housing such that wall wash lens cover faces wall surface.
- Push housing up into ceiling hole. Rotate housing towards wall such that plaster trim is flat on ceiling.







(EIb)




Installation Instructions

Downlight

Round and Square Accent Wall Wash Recessed Plaster Trim


Page 3

For multiple luminaire configuration, see below:



Plaster Trim may be broken on vertical and horizontal score marks to enable tighter arrangements.

Indent notches around perimenter may be used to calculate center marking distances.





3" ProTools WG-75RPTAWW-RPT WG-75SPTAWW-RPT

Installation Instructions

Downlight

Page 4

Round and Square Accent Wall Wash Recessed Plaster Trim

Step 4 - Apply Joint Compound


Apply joint compound onto Plaster Trim Housing using tape-and-joint technique. Joint compound should be flush with inside edge of housing. Clean excess while still wet.



Before Joint Compound



After Joint Compound



NOTE: Illustrations show conduit exiting from ceiling. This may not be the case in your installation.

Step 5 - Wiring

Cable Strain a Locate Fixture Insert/Driver Driver Relief Bracket Box assembly. **Box Cover** b Remove Driver Box cover. Loosen Cable Strain Relief Knock-out Bracket(s) and Hex Screws. o 0 Remove (unscrew) Knock-outs as necessary. Hex Screw **Driver Box** Need

Help




3" ProTools WG-75RPTAWW-RPT WG-75SPTAWW-RPT

Installation Instructions

Downlight

Round and Square Accent Wall Wash Recessed Plaster Trim





whitegoods




3" ProTools WG-75RPTAWW-RPT WG-75SPTAWW-RPT

Installation Instructions

Downlight

Round and Square Accent Wall Wash Recessed Plaster Trim



whitegoods





WG-75SPTAWW-RPT


Installation Instructions

Downlight


Round and Square Accent Wall Wash **Recessed Plaster Trim**

Page 7

Correct Seating for Round and Square Accent Wall Wash Cover/Lenses



Round Accent Wall Wash (RAWW)



Square Accent Wall Wash (SAWW)





