


Step 1 - Confirm Power Supply is Off!

Unpack luminaire unit. Unit ships in **two** major parts: Fixture Insert/Driver Box Assembly and Lens/Cover unless Remote Driver version was supplied, then Plenum-rated cable with bare leads is also provided. In this configuration, integral conduit and driver box are not included. However, a strain relief is added to where the low voltage wires exit. Remote drivers and housings are supplied by Inter-lux.



whitegoods

410 381 1497 inter-lux.com answers@inter-lux.com Inter-lux reserves the right to make technical changes without notice.



Cut-Out

Inside Trim


3" ProTools

WG-75RPTDL-RBT WG-75SPTDL-RBT

Step 2 - Ceiling Preparation

Cut appropriate size opening in the ceiling as shown below. Clear any insulation at least 3" from any part of the fixture or driver enclosure.

NOTE: Before Installation in dry location, remove supplied Gasket. For wet location, remove backing paper from the Gasket, expose adhesive, and apply Gasket to inside trim.



whitegoods

Locate Fixture Insert/Driver Box assembly.


b Remove Driver Box Cover. Cable Strain Driver Loosen Cable Strain Relief Relief Bracket Box Cover Bracket(s) and Hex Screws. Remove (unscrew) Knock-outs as necessary. Knock-out e 0 **NOTE:** Illustrations show conduit exiting from ceiling. This may not Hex Screw be the case in your installation. Driver Box Need Help?

> 410 381 1497 inter-lux.com answers@inter-lux.com Inter-lux reserves the right to make technical changes without notice.

Gasket



Incoming Power and Control Cables



Installation Instructions

Round and Square Standard Lens/Cover Recessed Bezel Trim

Downlight

Page 2




3" ProTools

WG-75RPTDL-RBT WG-75SPTDL-RBT

Installation Instructions

Downlight

Round and Square Standard Lens/Cover Recessed Bezel Trim







410 381 1497 inter-lux.com answers@inter-lux.com Inter-lux reserves the right to make technical changes without notice.




3" ProTools

WG-75RPTDL-RBT WG-75SPTDL-RBT

Installation Instructions

Downlight

Round and Square Standard Lens/Cover Recessed Bezel Trim



Turn Wing Adjustment Screws **clockwise** from below. Initial position shown at left. Wings are close to fixture body and raised to full height. As screws are turned, wings swing out, lower, and clamp Fixture Insert to inside of ceiling, as shown at right.

IMPORTANT: Be careful not to damage LED or Optic during installation process.









Installation Instructions


Downlight

Round and Square Standard Lens/Cover Recessed Bezel Trim


Page 5

Step 6 - Latching Lens cover inside Fixture Insert


a Check to ensure **all** push latches are **OPEN** before inserting




OPEN Latches Down



CLOSED Latches Up



b Ensure lens cover is fixed in place.









WG-75RPTDL-RBT WG-75SPTDL-RBT


Installation Instructions

The PTD3 Downlight may be outfitted with any of the following round and square Lenses/Covers:

Downlight


Round and Square Standard Lens/Cover Recessed Bezel Trim


Page 6







Round Recessed Cone (RRC)







Round Regressed Pinhole (RRPH)





Square Recessed Cone (SRC)






Square Regressed Pinhole (SRPH)





410 381 1497 inter-lux.com answers@inter-lux.com Inter-lux reserves the right to make technical changes without notice.





WG-75RPTDL-RBT WG-75SPTDL-RBT


Installation Instructions

The PTD3 Downlight may be outfitted with any of the following round and square lenses/covers:

Downlight

Round and Square Standard Lens/Cover Recessed Bezel Trim

Page 7



410 381 1497 inter-lux.com answers@inter-lux.com Inter-lux reserves the right to make technical changes without notice.





WG-75RPTDL-RBT WG-75SPTDL-RBT


Installation Instructions

The PTD3 Downlight may be outfitted with any of the following round and square lenses/covers:

Downlight


Round and Square Standard Lens/Cover Recessed Bezel Trim

Page 8





Round Micro Prismatic Opal (RMPO)



Square Micro Prismatic Opal (SMPO)



