INSTALLATION INSTRUCTIONS




RUBBER 3D OPTICS



Baltimore, MD 21227 Phone (410) 381-1497 inter-lux.com







WARNING:

CAUTION:

INSTALL PRODUCT IN ACCORDANCE WITH LOCAL AND NATIONAL ELECTRICAL CODES BY A QUALIFIED ELECTRICIAN

THIS IS AN ELECTRONIC DEVICE, CARE MUST

BE TAKEN DURING STORAGE AND HANDLING. STORE IN A CLEAN, COOL AND DRY LOCATION

ELECTROSTATIC DISCHARGE (ESD) CAN HARM THIS PRODUCT. AVOID STATIC DISCHARGE

WHILE HANDLING THIS PRODUCT



WARNING:

FAILURE TO COMPLY WITH THE INSTALLATION INSTRUCTIONS MAY RESULT IN DEATH OR SEVERE INJURY.



WARNING:

READ ALL SAFETY INSTRUCTIONS INCLUDED WITH LUMINAIRE BEFORE INSTALLING LUMINAIRE. SAVE INSTRUCTIONS FOR FUTURE USE.

CAUTION:

INTER-LUX IS NOT RESPONSIBLE FOR THE STRUCTURAL INTEGRITY OF THE BUILDING TO SUPPORT THE LUMINAIRE.
ADDITIONAL BACKING MAY BE REQUIRED.

LOCATE AND REVIEW ANY CONTRUCTION PLANS AND INTER-LUX RECORD DRAWINGS FOR ALL FIXTURE RUNS. IT IS RECOMMENDED TO LOCARE AND LAY OUT ALL COMPONENTS FOR EACH FIXTURE "RUN".
A FIXTURE RUN TIPICALLY CONSISTS OF JOINERS, LENGHTS OF HOUSING, AND ENDCAPS.
BE SURE TO IDENTIFY ALL CORRECT LENGHTS FOR EACH FIXTURE RUN.

Rubber 3D Optics

RUB-WH-3DOpt-39-7-CV-27-ELSP (E82216M20) RUB-WH-3DOpt-59-7-CV-30-ELSP (E82217W20) RUB-WH-3DOpt-118-7-CV-40-ELSP (E82218N20)

RUB-BL-3DOpt-39-7-CV-27-ELSP (E82219M20) RUB-BL-3DOpt-59-7-CV-30-ELSP (E82220W20) RUB-BL-3DOpt-118-7-CV-40-ELSP (E82221N20)

RUB-WH-3DOpt-39-7-CV-27-ELFL (E82216M30) RUB-WH-3DOpt-59-7-CV-30-ELFL (E82217W30) RUB-WH-3DOpt-118-7-CV-40-ELFL (E82218N30)

RUB-BL-3DOpt-39-7-CV-27-ELFL (E82219M30) RUB-BL-3DOpt-59-7-CV-30-ELFL (E82220W30) RUB-BL-3DOpt-118-7-CV-40-ELFL (E82221N30)





←INSTALLATION INSTRUCTIONS VIDEO

INSTALLATION INSTRUCTIONS




RUBBER 3D OPTICS

inter lux
3741 Commerce Dr. #306-308
Baltimore, MD 21227


Baltimore, MD 21227 Phone (410) 381-1497 inter-lux.com




1



2



3




4




Please wear the provided gloves

5




Extend the reel over, in a straight line (as much as possible)




Avoid bending the reel towards the top/down

6



Remove the entire reel from its shipping wheel before powering it



in its shipping wheel

Pag. 2

INSTALLATION INSTRUCTIONS



RUBBER 3D OPTICS





3741 Commerce Dr. #306 Baltimore, MD 21227 Phone (410) 381-1497 inter-lux.com
















Minimum bending radius 9.9"



Do not bend the fixture in a radius tighter than 9.9"



INSTALLATION INSTRUCTIONS 041000076ETL Phone (410) 381-1497 **RUBBER 3D OPTICS** inter-lux.com Do not twist the fixture at or close to the Do not suspend the cable entry fixture from its ends When installing it X>20" near water, allow for a minimum of 20" above water level

Pag. 4

INSTALLATION INSTRUCTIONS



RUBBER 3D OPTICS











WARNING!!!

Read cutting instructions in the next page thoroughly before cutting the fixture You will end up with an <u>unlit</u> section of up to 6.61" if directions are not followed.



 $X = 6.61" \times (1/2/3/..)$



First cut

Second

cut





0.25" + lit length after



a)

1





then do the second and final cut there. d) Energize and test again.

a third mark 0.25" towards the previously cut end.

95 2'



*Rubber 3D (non-Optics) version shown for illustration purposes only.



195 197 198 199 20 0 201 202 203 204




INSTALLATION INSTRUCTIONS



RUBBER 3D OPTICS










Warning!

If using a mounting profile, the profile needs to be cut 0.6" shorter (the end cap will not fit in the profile)









INSTALLATION INSTRUCTIONS


Baltimore, MD 21227


Phone (410) 381-1497 inter-lux.com












INSTALLATION INSTRUCTIONS




linea light









INSTALLATION INSTRUCTIONS


RUBBER 3D OPTICS





inter-lux.com


Linear profile with connector cavity


> ■E83034 ■E-K100009













2

Warning!

- Cables and connectors must be inserted into the connector cavity of the linear profile before fixing it to the ground/wall. The connector won't fit through the top opening of the linear profile.

 - The connector cavity at the bottom of the profile) only has room for one connection cross-section.

 - On continuous runs, a dedicated feed-entry is required per driver, at the start of the first reel powered by each
- new driver.

INSTALLATION INSTRUCTIONS





RUBBER 3D OPTICS


Phone (410) 381-1497

inter-lux.com


- Linear profile without connector cavity
 - **■** E99549 ■ E-K100007








2








Warning!
- On continuous runs, a dedicated feed-entry is required per driver, at the start of the first reel

INSTALLATION INSTRUCTIONS


linea light


RUBBER 3D OPTICS

inter-lux
3741 Commerce Dr. #306-308
Baltimore, MD 21227
Phone (410) 381-1497
inter-lux.com




Suggested spacing between clips: 4" o.c.





Suggested spacing between clips: 4" o.c.



INSTALLATION INSTRUCTIONS





RUBBER 3D OPTICS







FIXTURE REMOVAL





3 REPOSITION CLIP AND REINSTALL FIXTURE





INSTALLATION INSTRUCTIONS 041000076ETL Baltimore, MD 21227 Phone (410) 381-1497 inter-lux.com **RUBBER 3D OPTICS** 1 3 2 4 5

INSTALLATION INSTRUCTIONS 041000045ETL Phone (410) 381-1497 inter-lux.com **RUBBER 3D OPTICS** E99541 Flexible profile 3/4"H (19mm H) 1/2"H (13mm H) E-K100011 Flexible Profile (*upcoming version) 5/8" (16mm) W 39.7"L (1007mm L) Ø 5/32" (4mm) Screws and anchors not included Drill a 1/2" hole in the masonry/drywall, to allow the cable to go through. Rubber reel not included


INSTALLATION INSTRUCTIONS




RUBBER 3D OPTICS



E83351 Spike with bracket (for soft ground installation)



Clip without connector cavity Installation



INSTALLATION INSTRUCTIONS



RUBBER 3D OPTICS



Clip with connector cavity Installation



Linear profile with connector cavity Installation



INSTALLATION INSTRUCTIONS





RUBBER 3D OPTICS







E83352 Tilting bracket










INSTALLATION INSTRUCTIONS

























INSTALLATION INSTRUCTIONS


















INSTALLATION INSTRUCTIONS









INSTALLATION INSTRUCTIONS





RUBBER 3D OPTICS



3741 Commerce Dr. #306 Baltimore, MD 21227 Phone (410) 381-1497 inter-lux.com









Warning!

- On continuous runs, a dedicated feed-entry point is required per driver, at the start of the first reel powered by each new driver.

- Feed cables are 78.7" long. If a longer distance to the driver is needed, the installer should plan for an appropriate splice for the application, and account for voltage drop.

INSTALLATION INSTRUCTIONS




RUBBER 3D OPTICS

interelux
3741 Commerce Dr. #306-308
Baltimore, MD 21227

Baltimore, MD 21227 Phone (410) 381-1497 inter-lux.com





Warning!

- On continuous runs, a dedicated feed-entry point is required per driver, at the start of the first reel powered by each new driver.
- Feed cables are 78.7" long. If a longer distance to the driver is needed, the installer should plan for an appropriate splice for the application, and account for voltage drop.

Feed cables



E99688

Feed Cable 78.7" 2x#22AWG with 2 pole female connector



E99689

Feed Cable 78.7" 2x#22AWG with 2 pole male connector